

WARRANTY

www.britebelt.com

Thank you for purchasing the Brite Belt scrubber units, customized BRICK units, and cleaning pads. Brite Belt International, LLC hereby guarantees all of its products against manufacturing defects and will repair or replace at no cost if the defect is due to a manufacturing error. The product returned must be received within sixty (60) calendar days from the date of receipt of your original order. In order to be eligible for a replacement, your item must be returned with the accompanying original invoice with purchase order number. The warranty will be honored if upon receipt we determine that the defect is due to a manufacturing error and not sanitation misuse. If it is determined that the defect was due to misuse, the warranty will not cover replacement of a product.

The Brite Belt system is designed to dispense a variety of cleaning solutions, but Brite Belt International, LLC is not responsible for and does not specifically recommend or endorse solutions used in its scrubber tanks.

In order to prevent cross-contamination, the Brite Belt scrubber pads should be either thoroughly cleaned and sanitized or disposed of after each use. The Brite Belt scrubber units should be emptied and cleaned after use. The Brite Belt units and scrubber pads are not intended for direct food contact and should only be used in conjunction with an approved solution. Scrubber unit caps must be in place during use. Do not remove caps except when filling and cleaning.



DUAL LOCK REFURBISHING PROGRAM

If the Dual Lock comes loose, comes off, or the mushroom heads come off from continued use, Brite Belt International, LLC has a refurbishing program that is good for the lifetime of the unit.

The customer can return the scrubber at their cost via UPS to:

Brite Belt International LLC
1612 West K Avenue , Nevada , IA 50201

At no cost to you, Brite Belt International LLC will replace the Dual Lock and return the scrubber to your company, along with five (5) complimentary pads cut to your scrubber size.

BEST PRACTICES

- In the critical control point areas, we recommend that you only use scrubber pads once. Pad replacement is a minor cost compared to the efficacy they achieve. In areas that are less critical, pads can be cleaned, sanitized, and reused.
- To prevent cross-contamination, always use the same scrubber unit on the same belt. Identify each scrubber by placing on it a number that corresponds to the belt it cleans.
- Always empty the scrubbers of solution after you are done. Under certain conditions, the scrubber units can lose shape if they are used to store chemicals while in the upright position for long periods of time.
- Periodically check to see if the drainage orifices are flowing freely. Compressed air is a good method for removing clogs. Do not try to drill our plugged orifices. Doing so will dramatically change the solution flow rates.
- Open the vent cap to allow air into the scrubber so the solution will gravity flow out through the orifices. Keep the 2-inch fill caps tight during operation.

If you wish to increase the aggressiveness of the scrubber, you can do the following:

- 1 | Replace the scrubber pad once it is fully soiled.
- 2 | Keep the scrubber full of cleaning solution. The added weight will increase down pressure.
- 3 | Place added weight on top of the scrubber for more down pressure.

CONNECT WITH US

sales@britebelt.com

www.britebelt.com

(712) 830 3121 text or call

